

PIPING FOR BASIC COMBINATION DRILL-TAP TOOL AIR CIRCUIT



Hypneumat Inc. • 5900 West Franklin Drive • Franklin, WI 53132-9178 • (414) 423-7400 • Fax: (414) 423-7414



BASIC COMBINATION DRILL-TAP TOOL AIR CIRCUIT



THIS CIRCUIT IS A BASIC METHOD OF CONTROLLING HYPNEUMAT EQUIPMENT. CHECK LOCAL, STATE, & OSHA REGULATIONS FOR SPECIFIC CIRCUIT REQUIREMENTS.

Hypneumat Inc. • 5900 West Franklin Drive • Franklin, WI 53132-9178 • (414) 423-7400 • Fax: (414) 423-7414

AUTOMATIC DRILLING & TAPPING UNITS FOR COMBINATION DRILL-TAP TOOL AIR CIRCUIT

- 1. Turn Motor Selector Switch to "ON"
- 2. Push Cycle Start Button
 - a. Supplies power to Circuit (1CR)
 - b. Motor Forward Coil (MF) starts motor in clockwise rotation
- 3. Push Twin Palm Feed Buttons
 - a. Valve shifts and feeds unit under "HIGH PRESSURE"
- 4. After Drill Portion of tool breaks thru work piece and prior to tap portion of tool entering work piece, "Cam Switch" is set to actuate
 - a. High pressure is exhausted from lines
 - b. Hydra-Brake skip valve is actuated after .25 second delay from timer (eliminating control from Hydra-Brake)
 - c. Low pressure is introduced to unit
- 5. Depth Switch is actuated
 - a. Motor Forward Coil (MF) is dropped out
 - b. Motor Reverse Coil (MR) is energized and starts motor in counterclockwise rotation
 - c. Valve shifts and unit begins to retract
- 6. Unit Returns to full retract position and actuates Interlock Switch
 - a. Cam is dropped out
 - b. High pressure is again introduced to unit
 - c. Motor forward coil (MF) returns motor to clockwise rotation

EMERGENCY STOP

- 1. Push Emergency Stop Button
 - a. 1CR Master Relay drops out
 - b. Motor Forward Coil (MF) drops out
 - c. Valve shifts to retract position
- NOTE: A. If Tap is "NOT" in part, unit will rapid retract and motor coasts to stop
- NOTE: B. If Tap is "IN" part, motor will stop and unit will not rapid retract (see operation #2 for tap removal from part)
- 2. To return unit to full retract position, if tap is "IN" part
 - a. Push Emergency Stop button and hold down
 - b. Motor Reverse Coil (MR) is actuated and motor rotates counterclockwise
 - c. Tap leaves part and unit returns to full retract position
 - d. Release Emergency Stop Button

Visit us on the World Wide Web at http://www.hypneumat.com

Hypneumat Inc. 5900 West Franklin Drive Franklin, WI 53132-9178 Phone: (414) 423-7400 Fax: (414) 423-7414

